




HydroTap Touch-Free Wave

LED will indicate when hand is within range (1 - 5cm).


Scan the QR code to view additional features.



Boiling*



WARNING!
BOILING
WATER




*** MUST activate both the BOILING and LOCK sensors**



Chilled




Ambient




Bottle-fill:
Activate 2 sensors



Sparkling



Bottle-fill:
Activate 2 sensors



IMPORTANT! Do not use air-drying disinfectant sprays. Do not use abrasives to clean the sensor lenses at the sides, top and rear. This could cause permanent malfunction and void warranty.

To clean: Wipe with a damp cloth and then wipe dry with a clean, dry cloth.



809217