




Ventilation requirements Contact your local service provider if ventilation is not suitable

Clearance envelope


Position the Tap and the Command Centre as close together as possible.




Air outlet louvre (if required)
Cut-out in door/wall, towards
the top of the cabinet



Air inlet cut-out (required)
Cut-out in cabinet floor



HydroTap Tap options



Tap Positioning



Position the Tap to dispense into the sink, allowing clearance for a cup or teapot. Alternatively, mount the HydroTap Tap on a Font (available as an accessory).

Ø35mm hole for
HydroTap Tap






Font options

**Raised Font
with 135mm Extension
part no. 95258**



**Font
with 135mm Extension
part no. 90915**



**HydroTap G5
B60, BA60**

shown with "Classic Plus" Tap